

SHUR-TITE® PRODUCTS

SHUR-TITE® FLAT MOUNT DELINEATOR INSTALLATION INSTRUCTIONS

Mount bottom flat part of post flush with post or block-out. Make sure to have barrel portion of post all the way down touching the top of post or block-out. Drill 2 each – 3/16” pilot holes approximately 8” apart, then screw in 2 each – 1/4” x 2 1/2” lag bolts and washers (supplied by SHUR-TITE®).

