



**INSTALLATION INSTRUCTIONS FOR SHUR-TITE®
“CUP” MOUNT CTB DELINEATORS**

- Using a 1/4" drill bit, drill a hole with minimum 2" embedment depth.
- Blow the hole clean of dust and other material.
- Insert the anchor through the cup mount into the hole. Be sure the head is seated firmly against the cup mount and the anchor is at proper embedment.
- Drive the pin into the anchor body to expand it. Pin should be flush with head when finished.



SHUR-TITE® PRODUCTS

PO Box 2283, Round Rock, TX 78680 Phone: 512-218-9500 Fax: 512-388-0417
www.shur-tite.com