



P.O. BOX 2283, ROUND ROCK, TEXAS 78680 PHONE: 512-218-9500 FAX: 512-388-0417 www.shur-tite.com

Application Instructions for Reflective Sheeting on SHUR-TITE® Delineators

Reflective sheeting with pressure sensitive adhesive provides an excellent bond to our flame treated delineators. The adhesive is protected by a liner which is removed at the time of application, and the sheeting or film is then pressed into position.

Step 1: Surface Preparation

Surface Preparation Tools: Isopropyl Rubbing Alcohol, Soft Cloth and Flame Torch

- a. Application surface must be wiped clean to free any grease, dirt or other contaminants prior to the sheeting application. (Note: It is necessary to re-flame treat the delineator post by the end-user if they are placed in storage for two or more days after shipment is received.) If flame treating, run the flame for a few seconds across the area where the sheeting will be applied. Be careful, as running it too long will melt the plastic.
- b. The sheeting can be applied when air, sheeting and application surface temperatures are above 65° F. Applications below the specified minimum temperatures are not recommended.

Step 2: Application

Application Tool: plastic squeegee applicator or 2 inch rubber roller

- a. Before application, remove the liner by sharply flicking the sheeting edge toward the front face with the ball of the thumb or a fingernail. A small, sharp bend at a corner or edge will cause the liner to separate.
- b. Firmly hold the sheeting and pull the liner away in one motion, removing entire liner from adhesive.
- c. Align and press leading edge to surface with finger. Firmly squeegee or roll remaining unapplied portion to surface with firm, overlapping strokes.
- d. Press firmly with a plastic squeegee and re-squeegee all edges.