



P.O. Box 2283 - Round Rock, Texas 78680
(512) 218-9500

“Cup Mount” CTB Delineator

Adhesive Installation Instructions

- After cleaning the surface, mark the base location by drawing a chalk line around the outside of the base.
- Using a caulk gun, spread a minimum 1” to 1-1/2” wide bead of adhesive around the diameter of the base footprint.
- Apply with simple hand pressure in the above marked location. Assure a visible bead around the base and through the outer channel as shown below.

