



P.O. Box 2283 - Round Rock, Texas 78680
(512) 218-9500

“Cup Mount” CTB Delineator

Tapcon Screw Installation Instructions

- Using a 3/16” drill bit, drill a hole with minimum 2” embedment depth.
- Blow the hole clean of dust and other material.
- Using a drill, impact driver or hammer drill with a 5/16” nut driver, screw in the anchor until fully seated.

