



P.O. Box 2283 - Round Rock, Texas 78680
(512) 218-9500

Flat Mount “Guard Rail”

INSTALLATION INSTRUCTIONS

- Mount bottom flat part of post flush with post or block-out. Make sure to have barrel portion of post all the way down touching the top of post or block-out.
- Drill 2 each – 3/16" pilot holes approximately 8" apart.
- Screw in 2 each – 1/4" x 2 1/2" lag bolts and washers.

