



P.O. Box 2283 - Round Rock, Texas 78680
(512) 218-9500

Bolt Down for U-FLEX® Surface Mount

INSTALLATION INSTRUCTIONS

- Use supplied 5/8" green nylon plugs and 1/2" X 3 1/2" hex lag bolts with washers. Using a Hammer Drill with an Industrial 5/8" diameter bit, drill 4 ea - 5/8" diameter holes 3-1/2" deep using the Base as your pattern. Blow the holes clean.
- Insert the nylon plugs into the holes so that the top of the plugs are flush with the surface of the roadway (the top of the plugs must fit flush with the surface of the roadway).
- Position the Base over the holes with plugs in place and screw the 1/2" lag bolts with the washers into the nylon plug and tighten. Use a 3/4" socket to tighten bolts snugly to a (torque rating of min 30 – max 38 ft lbs). A impact wrench is recommended, however "DO NOT OVER TIGHTEN".
- After securing the base, insert the post into the base and secure with the L-Pin.

