



1920 North Weaver
Gainesville, TX 76240



512-966-9198



sales@shur-tite.com
www.shur-tite.com

SHUR-FLEX® SNOW POLE

INSTALLATION INSTRUCTIONS

- Soil anchor is a 2" square X 12 ga. galvanized, perforated steel tubing.
- A commercially available steel driver head is required for footing installation. These are also available from Shur-Tite Products.
- A manual or powered driver is used for driving square tubing into soil. Use a level to plumb the square tubing as it is being driven into ground.
- It is important to leave approximately one inch of square tubing showing above the ground surface. **See Photo Below**
- Insert Shur-Flex® joint fully into the square tubing anchor.
- Insert pin and attach cotter to complete installation. *It is preferred to use the top holes in the Shur-Flex® joint and the square tubing.



** If you experience solid rock or extremely hard ground conditions, the square tubing may be cut off at approximately 18" depth with a saws-all or port-a-band saw. If the square tubing is not cut square, you may use the bottom hole on the Shur-Flex® joint to attach.