



1920 North Weaver
Gainesville, TX 76240



512-966-9198



sales@shur-tite.com
www.shur-tite.com

SHUR-FLEX® SURFACE MOUNT

“RE-Flex”

INSTALLATION INSTRUCTIONS

- Use supplied 5/8” green nylon plugs and 1/2” hex lag bolts with washers. Using a Hammer Drill with an industrial 5/8” diameter bit, drill 4 holes, each 5/8” diameter and 3 1/2” deep using the base as your pattern. Blow the holes clean.
- Insert the nylon plugs into the holes so that the top of the plugs are flush with the surface of the roadway (the top of the plugs must fit flush with the surface of the roadway).
- Position the base over the holes with the plugs in place and screw the 1/2” lag bolts with the washers into the nylon plug and tighten. Use a 3/4” socket to tighten bolts snugly to a (torque rating of min 30-max 38 ft lbs). A impact wrench is recommended, however **“DO NOT OVER TIGHTEN.”**
- After securing the base, insert the post into the base and secure the L Pin.
- The 2 middle holes may be used if placing on a narrow headwall.

