



1920 North Weaver
Gainesville, TX 76240



512-966-9198



sales@shur-tite.com
www.shur-tite.com

CTB DELINEATOR “Cup Mount”

TAPCON SCREW INSTALLATION INSTRUCTIONS

- Using a 3/16” drill bit, drill a hole with minimum depth of 2”.
- Blow the hole clean of dust and other material.
- Using a drill, impact driver or hammer drill with a 5/16” nut driver, screw in the anchor until fully seated.

