



1920 North Weaver
Gainesville, TX 76240



512-966-9198



sales@shur-tite.com
www.shur-tite.com

CTB DELINEATOR “Cup Mount”

ADHESIVE INSTALLATION INSTRUCTIONS

- After cleaning the surface, mark the base location by drawing a chalk line around the outside of the base.
- Using a caulk gun, spread a minimum 1” to 1-1/2” wide bead of adhesive around the diameter of the base footprint.
- Apply with simple hand pressure in the above marked location. Assure a visible bead around the base and through the outer channel as shown below.

