



1920 North Weaver
Gainesville, TX 76240



512-966-9198



sales@shur-tite.com
www.shur-tite.com

CTB Delineator “Cup Mount”

Drive Pin Anchors Installation Instructions

- Using a 1/4” drill bit, drill a hole with minimum depth of 2”.
- Blow the hole clean of dust and other material.
- Insert the anchor through the cup mount into the hole. Drive the pin into the anchor body to expand it.
- Be sure the head is seated firmly against the cup mount and the anchor is at proper Depth. It is recommended using a punch to drive the pin until it is fully seated. Pin should be flush with head when finished.

