



1920 North Weaver
Gainesville, TX 76240



512-966-9198



sales@shur-tite.com
www.shur-tite.com

CABLE BARRIER DELINEATOR

INSTALLATION INSTRUCTIONS FOR SHUR-TITE® "SHORTIE" CABLE BARRIER DELINEATORS

- You will be provided with 2ea - 3/8" Beam Clamps as part of the installation kit.
To install the Cable-Barrier Delineator you should slide the bottom flattened portion of the delineator down the outside edge of the post 7" until you reach the rounded portion of the delineator. The delineator post should be suspended to the outside of the Steel H-Beam, allowing the Beam Clamps to provide the maximum support (see picture below).
- Using a 7/16" Socket or Crescent Wrench, first tighten the outer bolt to secure the delineator to the post. Then using a 9/16" deep socket or a Crescent Wrench securely tighten the inner set nut.
***It is important to tighten both the bolt and the set nut to achieve a secure fit.
- Be sure to utilize a level to plumb the post after installing the first nut and make slight adjustment As needed.
- After the nuts are in place and the delineator is plumbed tighten the set screws to lock the nuts in place and eliminate the ability of the nuts to loosen over time.
- The installation of this product should take no more than 1-2 minutes if properly equipped.

