



1920 North Weaver
Gainesville, TX 76240



512-966-9198



sales@shur-tite.com
www.shur-tite.com

U-FLEX® SURFACE MOUNT

“Bolt Down Method”

INSTALLATION INSTRUCTIONS

- Use supplied 5/8” green nylon plugs and 1/2” X 3 1/2” hex lag bolts with washers.
- Using a Hammer Drill with an industrial 5/8” diameter drill bit, drill 4 holes each 5/8” diameter width and 3 1/2” deep using the base as your pattern. Clean out each hole.
- Insert the nylon plugs into the holes so that the top of the plugs are flush with the surface of the roadway
 - *The top of the plugs **must** fit flush with the surface of the roadway.
- For tightening and securing, an impact wrench is recommended. Position the base over the holes with the plugs in place and screw the 1/2” lag bolts with the washers into the nylon plug and tighten. Uses a 3/4” socket, tighten the the bolts so they are secure to the base (a torque rating of min 30ft lbs-max 38ft lbs).
- After securing the base, insert the post into the base and secure with the L-Pin.

