



1920 N Weaver St
Gainesville, TX 76240



512-218-9500



sales@shur-tite.com
www.shur-tite.com

U-FLEX® DRIVEABLE

INSTALLATION INSTRUCTIONS

- Soil anchor consists of 2" square, 12-gauge galvanized perforated steel tubing.
- A steel driver head is required for installation (available from Shur-Tite Products or commercially sourced).
- Use a manual or powered driver to install the square tubing into the ground, ensuring it remains level and plumb during installation.
- Leave approximately 1" of the square tubing exposed above ground after installation (see reference image).
- Insert the U-Flex® post fully into the installed square tubing anchor.
- Secure the post by inserting the pin and attaching the cotter to complete installation.

For hard ground conditions:

- In solid rock or extremely hard soil, the square tubing may be cut at approximately 18" depth using a saws-all or port-a-band saw.
- If the cut is not square, use the bottom hole on the Shur-Flex® joint for proper attachment.

